

MONTGOMERY COUNTY FIRE AND RESCUE SERVICE DRIVER/OPERATOR TRAINING PROGRAM

Practical Examination Class "B" Apparatus


Practical Examination Objective: The driver candidate will explain the purpose of and perform a pre-trip inspection on the vehicle used for training. The Pre-Trip Inspection will be completed using guidelines below:

Pre-	trip Vehicle Inspection Test Name:	
for fl intac and	ehicle Overview: Start at the front of the vehicle looking uid leaks, and hanging wires. Are all body components at, not missing, or broken. Look down right side of body then left side looking for leaning which indicates weak or sen suspension.	(2)
th	ngine Compartment: Raise engine hood/cab making sure at hood springs, safety cables and cab lift piston safety locks re intact and not broken.	(2)
a	Oil – Oil level will be above the add mark. Check oil for foam and fuel. If oil is below the add mark add two quarts minimum of oil and re-check. Indicate type and amount.	(3)
b.	 Coolant – Check coolant by checking sight glass on reservoir. If no coolant is present indicate the proper mixture needed and how much to add. 	·(2)
C.	Power Steering Fluid – Check power steering reservoir for proper level. Make sure fluid is above the low or add mark. Some reservoir's have a cold full mark and a hot full mark. Indicate what type of fluid to add.	(2)

4/8/2015

d.	what type of fluid is in the transmission and its associated color. Does it smell burnt? Does it appear foamy? Check the transmission with the engine running and when the transmission has reached normal operating temperature. Check according to the dipstick marks or transmission pad based on the temperature of the fluid.	(3)
e.	Alternator - Check for loose or broken electrical connections. Is alternator securely mounted?	(2)
f.	Fan – All blades present and not bent or broken?	(2)
g.	Radiator – Is the radiator securely mounted? Is the radiator leaking?	(2
h.	Water pump and air Compressor – You must know if the water pump and air compressor is gear or belt driven. Are both units securely mounted? Are there missing parts? Are they leaking?	(4
i.	Power Steering pump – Is the power steering pump gear or belt driven? Are all hoses securely mounted to the pump? Are there any fluid leaks?	(2)
j.	Hoses – Check all hoses for cracking, cuts and bulges.	(2)
k.	Belts – Check all belts for cuts, cracks, and frays. Belts will have no more ¾ inch deflection.	(2)
l.	Wiring – Check all wires for fraying, broken connections, and broken wires.	(2)
m.	Batteries – Check batteries for leaks and corrosion. No loose or broken electrical connections. Batteries will be securely mounted.	(2)
n.	Steering system - Check steering shaft to steering box. Check the output shaft on the steering box. Pitman arm to drag link with castle nut and locking pin installed. Drag link to steering arm with castle nut and locking pin installed. Check for leaks at hoses and the steering box. No loose or broken steering components. No welds on steering system.	(5)

4/8/2015 2



4/8/2015

In Cab Inspection

10.	Seat_– The seats will be securely mounted to the floor with no missing parts. Seat will adjust forwards and backwards. Seat will adjust up and down. The seatbelt will function properly and will have no missing parts. Seatbelt strap will not be torn or cut. Locking mechanism will securely latch.	(3)
11.	Windshield – Windshield will be free from chips and cracks that obstruct the view of the driver. Dash will be free of debris that obstructs the performance of the defroster.	(2)
12.	Battery Switch – Battery switch will be free from debris, preventing accidental shut off.	(<mark>2</mark>)
13.	Gauges – With ignition on and motor running all gauges will operate in their normal operating range. Gauges should be illuminated from the back.	(3)
14.	Steering Wheel – Steering wheel will not be broken. Steering wheel will have no more play than 10 degrees or 10% of the diameter of the steering wheel. Horn will function.	(3)
15.	Lights – All lights (headlights and high beams, tail lights, brakes lights, marker lights,4-way) will function properly and be of proper color. Turn signals will function properly.	(5)
16.	Reverse Alarm – When unit is in reverse the reverse alarm will sound.	(<mark>2</mark>)
17.	In Cab General – Cab will be kept clean as to prevent items from rolling on the floor or falling off of the dashboard. The unit will be equipped with at least one wheel chock.	(3)
18.	Safety Equipment- present on vehicle. Minimum 5lb extinguisher, traffic flares or triangles	(3)
	Test Administrator Date	
	<u>100 pts</u>	
	Pass Fail Scor	

4/8/2015 4